Battery Insertion & Replacement / Reset Light to Normal mode



Reset the light to "Normal" mode
1. Press down the latches to release the sleeve.
2. Pull out the sleeve.
3. Take out the batteries.
4. Wait for 10 seconds before insert batteries back.
5. Reattach sleeve by aligning sleeve arrow mark with casing arrow mark.

Battery Insertion & Replacement
1. Press down the latches to release the sleeve.
2. Pull out the sleeve.
3. Take out the batteries.
4. Replace new batteries follow the orientation label.
5. Reattach sleeve by aligning sleeve arrow mark with casing arrow mark.

Mfd. for:
Energizer Holdings, Inc.,
St. Louis, MO 63141
©2011 Energizer